

## Model Number: 16162

### PROFESSIONAL AMPLIFIED SPEAKER BOX WITH USB, SD, MP3, BT With 2 Wireless Microphones


#### Technical Specifications

- 2-way amplified plastic loudspeaker
- woofer: 12" 30oz, 38mmVC, Tweeter: 25mm driver
- Frequency response: 55Hz-20KHz
- Sensitivity: 94+/-2dB
- With USB, SD, MP3, BT, FM, Echo
- Power: 180W
- Voltage: 230V, 60Hz



#### Notes

- Please read the entire attached document carefully before using the device for your reference.
- The power supply must match the demand of the device with reliable ground wire.
- All covering signal should be complied with the demand of device
- The device should be equipped far away high temperature, moisture and powerful electrical and magnetic field.
- Please don't use the organic cleaner but dry soft cloth to clear the device.
- When not in use, unplug the unit from the mains. 7. Set the unit to the lowest volume prior to switching it on.
- Set the unit to the lowest volume prior to switching it on.
- Only use suitable means of transportation if you want to move the speaker box



1. USB port
2. SD port
3. MP3 Player Button  
▶▶ Short press: Play/Pause  
MODE Press Switch between USB/SD/ FM/BLUETOOTH  
◀▶ Between RA/RO/RR  
◀◀ Press: Switch Return Long press Voice DOWN  
▶▶ Press: Switch Next Long press Voice UP
4. MIC input: XLR and 6.35 connector
5. Mic Level
6. Stereo Line input and output
7. MP3 and Line switch
8. Talk over  
Press this button, it makes the microphone function priority.
9. MP3/LINE LEVEL  
Adjust this knob, you can get different effect.
10. Echo Effect
11. Graphic EQ
12. Master Volume  
Adjust this knob to control the whole speaker's volume.
13. Two wireless microphone volume control
14. VHF microphone power  
Turn on this button, the wireless microphone will work.
15. 12V DC power
16. Indicator of battery level
17. Antennas of wireless microphone
18. Connector of power plug
19. 115/230V power switch
20. Power ON/OFF switch